

for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction. STEEL / ALUMINUM DOOR 03Z ANTI VANDAL BP-7 MOUNTING PLATE

DO NOT SCALE DRAWING DATE 09-12-11 T1179