

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

WOOD DOOR
5101 & F5101 SERIES
TOP ROD ONLY EXIT DEVICE
BP-2 MOUNTING PLATE

DATE

CORPORATION

DO NOT SCALE DRAWING

3-29-10 TEMPLATE T1090