



INSTRUCTIONS FOR INSTALLING ADJUSTABLE GATE PLATE (GTPLKIT & GTPL230X)

Drawing # 105660

Table of Contents	Sheet
Device parts breakdown view with part numbers.....	2
Install gate plate and strike bracket.....	3
Install Value Series or Advantex mounting plate and strike.....	4
Install 03GS, 08GS or 08GSN options for Value Series/Advantex.....	5
Install ECL-230X mounting plate.....	6
Install 03GS option for ECL-230X.....	7

Should you have a Question/Problem with your Detex device please call Detex Technical Support from the job site at 1-800-729-3839 and choose option 2 on our menu. Please do not return the product to the distributor.

For **WARRANTY** information,
scan code below or
go to www.detex.com/warranty




Owner's Copy

104918 sheet 1

For device installation videos,
scan code below or
go to www.detex.com/videos






NOTE: Gates vary in many ways and installations will vary. This instruction provided the steps to install gate plate. The installer must use their best judgement when adjusting the strike bracket and exit device for the best installation.

Installing the Adjustable Gate Plate

Tools required: Safety glasses, Pencil, Level, Power drill, Screwdriver, Tape measure


7-3/4" MAXIMUM if using optional 03GS Lockbox

Latch side of gate



STEP 1:

Mark the BOTTOM of the PLATE
28" from the floor/ground




For added security & for large gaps between gate and post, use Gate Latch Protector.
Mounts between gate and plate to cover gap.



Hinge side

TOP VIEW

STEP 2: Install plate assembly using 3 tek screws per side.
Plate assembly mounts to INSIDE of gate.




This edge to hinge side of gate

Adjust width as required to fit gate

Drain holes need to be on the bottom

STEP 3:

Install strike bracket using acorn nuts & flatwashers



U-Bolt

Approximately

1" overlap (varies with gate construction)

Note: Strike bracket acts as the gate stop

Tighten nuts after positioning bracket


40" from floor/ground

Detex panic device gate mounted instructions (Value Series shown, Advantex similar) (continued from sheet 3)


STEP A: Install device mounting plate

Detex panic device mounting hardware supplied with Detex device.

A1: Install device plastic template into mounting plate




A2: Align strike holes in template with strike holes in bracket




A3: Mark & drill holes for mounting plate.

A4: NOTE: IF 03GS Lock Box or 08GS / 08GSN Trim Spacers are to be used, see next page before doing step A4.


Use tek screws & lockwashers supplied in device hardware kit to attach mount plate to gate (machine screws and nuts also supplied).



A5: Install 2 tek screws to secure strike bracket to gate pole using 2 of the pre-drilled bracket holes. Strike bracket must be parallel with gate plate.




Install strike per device instructions. Hardware included with exit device.




Continue exit device installation using instructions supplied with exit device.

OPTIONAL: Required for 03GS Lock Box and 08GS / 08GSN Trim Spacers




For 03GS Lock Box


A7: Drill four 1/4" holes at the locations shown below.



A8: Mount Lock Box




A9: Mount cylinder in 03GS Lock Box




For 08GSN Trim Spacer

A7: 08GSN ONLY: Drill two 1/4" holes at the locations shown below.




A8: Mount 08GSN Trim Spacer



For 08GS Trim Spacer

A8: Mount 08GS Wide Trim Spacer
The trim screws hold the spacer in place.




ECL-230X device gate mounted instructions (continued from sheet 3)


STEP B: Install device mounting plate

Detex panic device mounting hardware supplied with Detex device.

B1: Install adapter plate kit (p/n 104345)




B2: Position template against adapter plate and align template \varnothing 40" from floor/ground




B3: Mark (6) mounting plate holes

If 03GS Box is to be used,
mark these locations as well.
See next page for installation
before proceeding to step B4




B4: Use four (4) tek screws & lockwashers supplied in device hardware kit to attach device mount plate to gate in locations shown (machine screws & nuts also supplied)




B5: Install strike

1/4-20 x 5/8"
PPH screws




B6: Install 2 tek screws to secure strike bracket to gate pole using 2 of the pre-drilled bracket holes. Strike bracket must be parallel with gate plate.



Continue exit device installation using instructions supplied with exit device.

ECL-230X with 03GS Box






B7: Draw vertical line through these marked locations


B8: Drill 1/2" hole at the intersection of the 2 lines

device \mathbb{C}

B9: Drill four 1/4" holes at the locations shown below.



B10: Mount Lock Box



B11: Mount cylinder in 03GS Lock Box

Continue exit device installation using instructions supplied with exit device.